


Yılmaz Redüktör DR573.00 Paralel Milli Redüktör

TEMEL MODEL / DR573.00

DR573.00, D57 gövdesinde üç kademeli paralel milli aktarım sağlar. 60 mm kovanla yük miline bağlanan bu yapıda tork kolunun veya diğer sabitlemenin yerleşimi makine hareketleriyle uyumlu olmalıdır. Çevrede titreşen veya hareket eden parçaları da tarif ederek bağlantı çözümünü tahrik seçimiyle birlikte değerlendirebilirsiniz.



Resmî aile görseli

Doğrulanmış teknik referanslar

Model kodu	DR573.00
Gövde grubu	D57
Dişli yapısı	Paralel milli helisel
Kademe	3
Giriş bağlantısı	Direkt motor akupleli; motor seçimi gerekli
Çıkış / montaj	Standart delik milli (.00)
Standart kovan çapı (mm)	Ø60
Gövde grubu nominal torku (Nm, referans)	3.000

Sabitleme noktasının konumunu ve makinedeki hareketli bölgeleri işaretleyin.

Gövde sabitlemesi herhangi bir noktadan yapılabilir mi?

Hayır. Üreticinin bağlantı düzeni ve makinenin yük yolu dikkate alınarak uygun montaj tasarlanmalıdır.


DR573.00 için montaj düzeninizi kapsayan seçim teklifi alın.

Temel model: tahvil, motor/giriş bağlantısı ve montaj pozisyonu teyit edilir. Gövde torku referanstır; seçili takımın çıkış değeri değildir. Görsel aileye aittir; boyut ve motor değişebilir.

Yılmaz Redüktör DR573.00 Parallel-Shaft Gearmotor

BASE MODEL / DR573.00

DR573.00 provides three-stage parallel-shaft transmission in the D57 housing. With a 60 mm bore connection, torque-arm or other restraint placement must suit the machine arrangement. Describe nearby moving or vibrating components so the mounting solution can be reviewed with drive selection.



Official family visual

Verified technical references

Model code	DR573.00
Housing group	D57
Gear type	Parallel-shaft helical
Stages	3
Input connection	Directly motor-coupled; motor selection required
Output / mounting	Standard hollow output (.00)
Standard hollow bore (mm)	Ø60
Housing-group nominal torque (Nm, reference)	3000

Mark the restraint point and moving regions of the machine.

Can the housing be restrained at any convenient point?

No. Use the manufacturer's mounting arrangement and consider how loads pass into the machine structure.

Request a DR573.00 selection proposal covering the mounting arrangement.

Base model: ratio, motor/input interface and mounting position require confirmation. Housing torque is a reference, not a configured output rating. Family image; exact size and motor may differ.