
Yılmaz Redüktör MR002 Ayaklı Helisel Redüktör

TEMEL MODEL / MR002

MR002, ayak bağlantılı küçük tahrik düzenlerinde iki kademeli helisel yapı sunar. M00 gövde grubunun 20 mm çaplı çıkış mili, kaplin ve bağlantı yerleşimini değerlendirirken somut bir başlangıç noktasıdır. Direkt motor akupleli bu modelde motor gücünü yalnız gövde büyüklüğüne göre seçmeyin; istenen çıkış devri ve yükün kalkış davranışı teklifin esasını oluşturmalıdır.



Resmî aile görseli

Doğrulanmış teknik referanslar

Model kodu	MR002
Gövde grubu	M00
Dişli yapısı	Helisel
Kademe	2
Giriş bağlantısı	Direkt motor akupleli; motor seçimi gerekli
Çıkış / montaj	Ayak bağlantılı, dolu mil
Standart çıkış mili çap/boy (mm)	Ø20/40
Gövde grubu nominal torku (Nm, referans)	82

Mevcut kaplinin delik çapını, mil yüksekliğini ve kalkış sayısını birlikte bildirin.

MR002 kodu motor gücünü belirler mi?

Hayır. Kod temel redüktör tipini tanımlar; motor gücü, tahvil oranı ve montaj pozisyonu ayrıca seçilir.


MR002 için makine devrinizi paylaşın, uygun motorlu teklif isteyin.

Temel model: tahvil, motor/giriş bağlantısı ve montaj pozisyonu teyit edilir. Gövde torku referanstır; seçili takımın çıkış değeri değildir. Görsel aileye aittir; boyut ve motor değişebilir.

Yılmaz Redüktör MR002 Foot-Mounted Helical Gearmotor

BASE MODEL / MR002

MR002 provides a two-stage helical drive with foot mounting. Its M00 housing group uses a 20 mm output shaft, giving a practical starting point for coupling selection. The directly coupled motor must be sized around output speed and starting load; housing size alone does not define the motor power.



Official family visual

Verified technical references

Model code	MR002
Housing group	M00
Gear type	Helical
Stages	2
Input connection	Directly motor-coupled; motor selection required
Output / mounting	Foot mounted, solid output shaft
Standard output shaft diameter/length (mm)	Ø20/40
Housing-group nominal torque (Nm, reference)	82

Provide coupling bore, shaft centre height and starts per hour.

Does MR002 specify motor power?

No. It identifies the base gearbox model; motor power, ratio and mounting position require selection.

Request an MR002 quotation using your required machine speed.

Base model: ratio, motor/input interface and mounting position require confirmation. Housing torque is a reference, not a configured output rating. Family image; exact size and motor may differ.