
Yılmaz Redüktör MR772 Ayaklı Helisel Redüktör

TEMEL MODEL / MR772

MR772, M77 gövde grubunda iki kademeli ayaklı helisel redüktördür. 90 mm çaplı çıkış mili ve 170 mm mil boyu, makine tarafındaki bağlantının ölçülmesi için belirgin referanslar sunar. Büyük bağlantı elemanları kullanıldığında yükün mil üzerinde nerede uygulandığını paylaşmak, rulman ve mil yükü kontrolünü teklif sürecine taşır.



Resmî aile görseli

Doğrulanmış teknik referanslar

Model kodu	MR772
Gövde grubu	M77
Dişli yapısı	Helisel
Kademe	2
Giriş bağlantısı	Direkt motor akupleli; motor seçimi gerekli
Çıkış / montaj	Ayak bağlantılı, dolu mil
Standart çıkış mili çap/boy (mm)	Ø90/170
Gövde grubu nominal torku (Nm, referans)	8.000

Aktarım elemanının ağırlığını ve kuvvet uygulama noktasını çizimde gösterin.

Ağır kaplinin etkisi yalnız torkla ifade edilir mi?

Hayır. Ağırlık ve yerleşimden kaynaklanan yükler ayrıca değerlendirilir; bağlantı konumu önemlidir.


MR772 için mil yüklerini dikkate alan bir teklif hazırlayalım.

Temel model: tahvil, motor/giriş bağlantısı ve montaj pozisyonu teyit edilir. Gövde torku referanstır; seçili takımın çıkış değeri değildir. Görsel aileye aittir; boyut ve motor değişebilir.

Yılmaz Redüktör MR772 Foot-Mounted Helical Gearmotor

BASE MODEL / MR772

MR772 is a two-stage foot-mounted helical gearbox in the M77 group. A 90 mm diameter and 170 mm length define its output-shaft reference. With large transmission components, the location of applied force matters, so include it in the enquiry for shaft and bearing-load assessment.



Official family visual

Verified technical references

Model code	MR772
Housing group	M77
Gear type	Helical
Stages	2
Input connection	Directly motor-coupled; motor selection required
Output / mounting	Foot mounted, solid output shaft
Standard output shaft diameter/length (mm)	Ø90/170
Housing-group nominal torque (Nm, reference)	8000

Mark component weight and the force application point on the drawing.

Is a heavy coupling described by torque alone?

No. Weight and position introduce additional loads that must be assessed separately.

Request an MR772 quotation that accounts for shaft loading.

Base model: ratio, motor/input interface and mounting position require confirmation. Housing torque is a reference, not a configured output rating. Family image; exact size and motor may differ.