Yılmaz Redüktör NR103 Flanşlı Helisel Redüktör

TEMEL MODEL / NR103

NR103, üç kademeli N10 helisel redüktörü flanşlı makine bağlantısıyla sunar. Çıkış miline takılan kaplinin göbek boyu, 50 mm mil boyuyla birlikte değerlendirilmelidir. Özellikle dar flanş önü mesafelerinde kaplin ve koruyucu yerleşimini önceden netleştirmek, teklif edilen tahrikin sahadaki montaj koşullarıyla eşleşmesine yardımcı olur.



Resmî aile görseli

Doğrulanmış teknik referanslar

Model kodu	NR103
Gövde grubu	N10
Dişli yapısı	Helisel
Kademe	3
Giriş bağlantısı	Direkt motor akupleli; motor seçimi gerekli
Çıkış / montaj	Flanş bağlantılı, dolu mil
Standart çıkış mili çap/boy (mm)	Ø25/50
Gövde grubu nominal torku (Nm, referans)	140

Flanş ön yüzü ile tahrik edilen mil arasındaki mesafeyi ölçün.

NR103'ün 50 mm mil boyu neyi ifade eder?

Gövde tablosundaki çıkış mil boyudur; bağlantı elemanının gerçek kavrama ve boşluk ihtiyacı ayrıca kontrol edilir.

NR103 için kaplin mesafenizi belirterek teklif alın.

Temel model: tahvil, motor/giriş bağlantısı ve montaj pozisyonu teyit edilir. Gövde torku referanstır; seçili takımın çıkış değeri değildir. Görsel aileye aittir; boyut ve motor değişebilir.

Yılmaz Redüktör NR103 Flange-Mounted Helical Gearmotor

BASE MODEL / NR103

NR103 combines three-stage N10 helical gearing with flange mounting. Coupling hub length should be assessed against the 50 mm output-shaft length. Where space ahead of the flange is limited, define the coupling and guard layout before ordering the drive.



Official family visual

Verified technical references

Model code	NR103
Housing group	N10
Gear type	Helical
Stages	3
Input connection	Directly motor-coupled; motor selection required
Output / mounting	Flange mounted, solid output shaft
Standard output shaft diameter/length (mm)	Ø25/50
Housing-group nominal torque (Nm, reference)	140

Measure the distance from flange face to the driven shaft.

What does the listed 50 mm shaft length mean?

It is the housing-table output-shaft length; actual engagement and clearance requirements need separate checking.

Request an NR103 quotation with your coupling-space requirement.

Base model: ratio, motor/input interface and mounting position require confirmation. Housing torque is a reference, not a configured output rating. Family image; exact size and motor may differ.